

IMPORTANT

TOPRING

How to start your refrigerant air dryer

Models 49.500 to 49.542 / Models 49.561 to 49.583



**PRESS and HOLD
the ON/OFF button
for 8 seconds**

The compressor light will turn ON.

The compressor and its fan will turn ON after a 2 minute security delay.

The digital display stays ON even when the dryer is turned OFF.

96.885 Oct 2019

IMPORTANT

TOPRING

Comment faire la mise en marche de votre sécheur d'air frigorifique

Modèles 49.500 à 49.542 / Modèles 49.561 à 49.583



**Appuyer et maintenir
le bouton ON/OFF
durant 8 secondes**

Le témoin du compresseur s'allumera.

Le compresseur et le ventilateur se mettront en marche après un délai de sécurité de 2 minutes.

L'affichage numérique demeure allumé même lorsque le sécheur est hors fonction.

96.885 Oct 2019

IMPORTANT

TOPRING

Comment faire la mise en marche de votre sécheur d'air frigorifique

Modèles 49.500 à 49.542 / Modèles 49.561 à 49.583



Appuyer et maintenir le bouton ON/OFF durant 8 secondes

Le témoin du compresseur s'allumera.

Le compresseur et le ventilateur se mettront en marche après un délai de sécurité de 2 minutes.

L'affichage numérique demeure allumé même lorsque le sécheur est hors fonction.

96.885 Oct 2019

IMPORTANT

TOPRING

How to start your refrigerant air dryer

Models 49.500 to 49.542 / Models 49.561 to 49.583



PRESS and HOLD the ON/OFF button for 8 seconds

The compressor light will turn ON.

The compressor and its fan will turn ON after a 2 minute security delay.

The digital display stays ON even when the dryer is turned OFF.

96.885 Oct 2019